

16633 Foltz Industrial Parkway • Strongsville, Ohio 44149, U.S.A. • Telephone (440) 572-1500 • Fax (440) 238-8828 www.clark-reliance.com

Recommended Storage and Handling Procedures for Jerguson Gages and Valves

- 1. Upon receipt of materials, open crates / boxes and inspect all materials to ensure no damage has occurred during transit. Based upon shipping terms, file a claim with Clark-Reliance or the applicable freight carrier for damages.
- 2. Replace and fasten down lid of crate / box.
- 3. Store all materials in a dry, clean indoor environment, protected from the elements or corrosive fumes.
- 4. Materials shall remain inside of the crate / box until it is ready to be installed.
- 5. Materials should be stored in a place where they can neither fall or be struck by falling objects.
- 6. Some gasket materials have a 5 year shelf life. Units should not be stored beyond 3 years.
- 7. Some sight gages are shipped unassembled, as they are to be welded into position and then assembled. Individual pieces should be carefully stored in a manner to avoid damage or loss until installation is required.
- 8. Gage glass requires special attention. It should not be stored or mixed with objects that may cause damage and should remain wrapped or boxed until use.





